

How to use the cold beverage machine ?

1.To fall prepared beverage into the crock , the height of it is should not exceed the standard height , otherwise the beverage will flow into the churn-dasher from the dasher tube,which will make the dasher burn .

2.The temperature of the beverage should not too high (not exceed 35), otherwise it will make bad effect ion for the refrigeration .

3.Plug in the supply power to the 3 hole socket , the grounding hold should connect with the protecable wire or fixture to ensure the safety .

4.To turn the switch on the position of refrigeration , press down the refrigeration switch ,the compressor fan starts running and refrigeration system starts working .Then start the dasher to mix or start the spewing switch to spew.

5.When the beverage becomes to the suitable temperature , please make the cup against the push board lightly .the beverage will flow into the cup from the outlet mouth .

6.when the temperature reduces to the certain degree , the refrigeration will stop running because of the influence from the temperature Controller .And when it increases, it will start automatically again .

7.It should re-start after 5 minutes if it turn off suddenly or stop

temporarily .otherwise it will damage the compressor .